

Assembly instruction

Series SMB, SMC, SMS

0000179013

Old instruction No. 03077



Tools and materials required:
Stanley-blade
Scissors
Crimp tool (see table below)

Straight connectors for flexible cable

Cable entry: SUHNER Full-Crimp

Connector types: (e.g.)

11_SMC/S-50-1-10

11_SMB/C-50-2-10





21_SMB-50-1-10

21_SMB/C-50-2-10

24_SMB/C-50-1-10

24_SMB/C-50-2-110


This connector is supplied in 3 parts.	Suitable cables: (e.g.)	RG 178 B/U	RG 174/U
	Centre contact:	cavity 1	cavity 1
	Braid:	cavity A	cavity A
	Crimp tool:	1, 2, A (red)	1, 2, A (red)




Slide ferrule A onto cable.

Prepare cable according to diagram.


CAUTION: Do not damage braid, inner conductor and dielectric of cable!



Push contact B over inner conductor of cable to abut dielectric and crimp.



Splay out braid and insert cable in connector body C. Ensure that braid lies above the crimp neck.
When cable dimension 2 is used Center-Pin has to snap in.



Slide ferrule A over braid and crimp as close to connector body C as possible.

The cable assembly of R.F. connectors can only be done by well trained assembly staff and suitable assembly equipment.
Huber+Suhr's skilled staff and specialised equipment are available to carry out complete R.F. lead-assembly on your behalf.
We mount your connectors on cables at economic prices! Please contact our representative for further details of this service.

Revision	B
Date	01.04.2015
Initiator	4726/Bom

Deutscher Text: siehe Rückseite



Benötigte Hilfsmittel:

Stanley-Messer

Schere

Klemmwerkzeug (siehe Tabelle)

Gerade Verbinder für flexible Kabel

Kabeleinführung: SUHNER Voll-Klemmung

Verbinder-Typen: (z.B.)

11_SMC/S-50-1-10

11_SMB/C-50-2-10

21_SMB-50-1-10

21_SMB/C-50-2-10

24_SMB/C-50-1-10

24_SMB/C-50-2-110

Dieser Verbinder wird in 3 losen Teilen geliefert.

Geeignete Kabel: z.B.

RG 178 B/U

RG 174/U

Innenleiter:

Aussparung 1

Aussparung 1

Aussenleiter:





Aussparung A

Aussparung A

Klemmwerkzeug:

1, 2, A (rot)


1, 2, A (rot)




Hülse A auf das Kabel schieben.

Kabel gemäss Figur abisolieren.

ACHTUNG: Abschirmung, Dielektrikum und Innenleiter nicht beschädigen!




Kontakt B über Kabelinnenleiter bis zum Dielektrikum stossen und klemmen.



Abschirmung leicht aufspreizen und Kabel in Gehäuse C einführen.

Abschirmung muss über Klemmhals liegen. Innenleiter muss bei Kabeldimension 2 einschnappen.



Hülse A über Abschirmung schieben und möglichst nahe am Gehäuse C klemmen.